

PRCN PRCN-UPF-C	CP-205-R13-03	Effective Date:	11/02/23
NOTE: PRCN Effective Date cannot precede effective date of associated document.			
⊠ In	tent Change	☐ No	n-Intent Change
Associated Document Number:	UPF-CP-205		Rev: 13
Associated Document Title:	Personal Protective Equipmen	t and Safe W	ork Apparel
Justification for Change:	Procedure being updated to a Procedural Requirements for		

Through document change

From: STARRT; Safety Task Analysis and Risk Reduction Talk

To: FLHA; Field Level Hazard Assessment

Change Section 3.1.10

From:

Wear appropriate, high visibility apparel when required in accordance with **Table 1**. High visibility apparel includes safety vests, jackets, shirts, and other personal protective safety clothing that is intended to provide visibility during both daytime and nighttime usage and that meets the Performance Class 2 requirements of ANSI 107, *American National Standard for High-Visibility Apparel and Headwear*.

To:

Project personnel working in active construction areas must wear appropriate, high-visibility vests (or equivalent clothing), per ANSI 107-2004, *American National Standard for High-Visibility Apparel and Headwear* as follows:

- ANSI/ISEA 107 Type "R" Class 2 General construction areas
- ANSI/ISEA 107 Type "R" Class 3 When exposed to traffic from public access highway/street right-of-way or highway/street temporary traffic control zones during nighttime activities
- High visibility vests must be rated for flame resistance where hot work processes may negatively impact the vest or the wearer's safety

Additionally, the selection of apparel color shall be in accordance with Table 1 for the specific activity performed.

Remove from Section 3.1.10 Table 1: Traffic Watch (Flagger)

Add to Section 5.1

MUTCD, Manual on Uniform Traffic Control Devices for Streets and Highways – 2009 Edition

In Section 5.2 change

From:

ANSI 107, American National Standard for High-Visibility Apparel and Headwear

To:

ANSI/ISEA 107-2004, American National Standard for High-Visibility Apparel and Headwear

Add to the Definitions section in Appendix A the following:

Flagger—a person who actively controls the flow of vehicular traffic into and/or through public access highways, street right -of-way or highway/street temporary traffic control zones using hand-signaling devices

Highway—a general term for denoting a public way for purposes of vehicular travel, including the entire area within the right-of-way

Street—see Highway

Temporary Traffic Control Zone—an area of a highway where road user conditions are changed, because of a work zone or incident, by the use of temporary traffic control devices, flaggers, uniformed law enforcement officers, or other authorized personnel

UCN-23182 (01-17-2023) Y15-95-235 Y15-95-236 Page 1 of 2

RC-UPF DMC 10/04/23 13:55



Preparer				
UPF ES&H Issues	Anton R. Panev	Am Por	10/03/23	
Management		Printed Name/Signature	Date	
		Approval		
CNS UPF ES&H Construction	Donald E. Sproul	Donald Som	10/03/23	
		Printed Name/Signature	Date	
UPF ES&H Manager, BNI	Kieran S. Kelly	Am Alba	10/04/23	
		Printed Name/Signature	Date	
UPF Site Manager	Gary J. Cough	Sary Coresh	10/03/23	
		Printed Name/Signature	Date	



PRCN Number:	RCN-UPF-C	P-205-R13-02	Effective Date:	08/07/23
NOTE	: PRCN Eff	fective Date cannot precede eff	ective date	e of associated document.
		ent Change	_ n	Non-Intent Change
Associated Docur Number:	nent	UPF-CP-205		Rev: 13
Associated Docur	nent Title:	Personal Protective Equipmen	t and Safe	Work Apparel
Justification for Cl	hange:	CR: 25774-00-GCA-GAM-042 Safety - MEB/MPB Hot Work I		e to Implement Work Control for Worker [*CA]
Identify the scope any new, remove			-through fo	or deletions, colored text for additions) of
Update Section 3	3.1.11.1			
From: Body-protection-requirements-for-awkward-or-confined hot work-positions (e.g., prone, crouching) include hazard-risk-category-2-pants, trousers, or leggings.				
Leather cape sleeves or shoulder covers made of leather or flame resistant material may be required while performing hot work in an overhead configuration.				
To : For heavy work (e.g., Carbon Arc Cutting over 500Amps, Oxyfuel Gas Weld over 1/2" plate), flame-resistant leggings or other equivalent means shall be used to give added protection to the legs, when necessary.				

Cape sleeves or shoulder covers with bibs made of leather or other flame-resistant material shall be worn during overhead welding, cutting, or other operations, when necessary.

Preparer				
UPF ES&H Issues	Anton R. Panev Am Pur		08/07/23	
Management		Printed Name/Signature	Date	
		Concurrence		
CNS UPF ES&H Construction	Donald E. Sproul	Donald Edul	07/31/23	
		Printed Name/Signature	Date	
		Approval		
UPF ES&H Manager, BNI	Kieran S. Kelly		07/31/23	
		Printed Name/Signature	Date	
UPF Site Manager	Gary J. Cough	Sary Cough	08/07/23	
_		Printed Name/Signature	Date	

RC-UPF DMC 08/07/23 09:39





PRCN PRCN-UPF-CP-205-F	R13-01	Effective Date:	05/24/23		
NOTE: PRCN Effective	NOTE: PRCN Effective Date cannot precede effective date of associated document.				
☐ Intent Cha	nge	⊠ Nor	n-Intent Change		
Associated Document UPF-Number:	-CP-205		Rev: 13		
Associated Document Title: Person	onal Protective Equipmen	t and Safe Wo	ork Apparel		
Justification for Change: Clarit	fication				
any new, removed, or changed conte		through for de	eletions, colored text for additions) of		
Update Section 3.1.2					
From:					
Personnel assigned to or visiting Construction/Warehousing areas shall wear sturdy, ankle high, safety toed footware that meet or exceed the requirements of ASTM F2413, Standard Specification for Performance Requirements for Protective (Safety) Toe Cap Footwear. Footwear such as tennis/athletic shoes, open-toed shoes, sandals, moccasins, high heels, boat shoes, and mules are not acceptable footwear.					
То:					
Personnel assigned to or visiting Construction/Warehousing areas shall wear safety-toed, sturdy leather work boots that cover the ankle and meet or exceed the requirements of ASTM F2413, <i>Standard Specification for Performance Requirements for Protective (Safety) Toe Cap Footwear</i> . Footwear such as tennis/athletic shoes, open-toed shoes, sandals, moccasins, high heels, boat shoes, and mules are not acceptable footwear at construction and warehousing locations.					

Preparer				
UPF ES&H Issues	Anton Panev	Am Park	05/24/23	
Management		Printed Name/Signature	Date	
	Approval			
UPF ES&H Manager, BNI	Kieran S. Kelly	Al Do	05/22/23	
		Printed Name/Signature	Date	
UPF Site Manager	Gary J. Cough	Sary Cough	05/24/23	
		Printed Name/Signature	Date	

RC-UPF DMC 05/24/23 14:05





Preparer:		
	Jill S Logsdon	09/21/21 Date
	UPF Construction Issues Management	Date
Approval:	A NO h	00/04/04
	Kieran S. Kelly UPF ES&H Manager, BNI	
	James M Horning James M. Horning	09/21/21 Date
	UPF ES&H Manager, CNS	00/04/04
	Robert S. Solberg UPF Site Manager	
		10/21/21

Effective Date

REVISION LOG

Re	evision 13
•	Revised Section 3.0, Requirements, in response to Condition Report 25774-000-GCA-GAM-03184, Arc Between Welder Safety Toe Boot/Welding Whip (ORPS Reportable NA-UPO-CNS-UPRPROJ-2021-0007)
	 Added Section 3.1.11, Body Protection, and Section, 3.1.11.1 Welding and Associated Hot Work Activities, to specify PPE requirements for personnel performing welding and hot work as requested by the Authority Having Jurisdiction
•	An evaluation determination has been performed confirming that this Procedure does not implement requirements tracked in the Programmatic Requirements Management System (PRMS)
•	No forms have been revised as a part of this revision
•	Other changes include:
•	 Revised Section 3.1.1, Safe Work Apparel, to clarify appropriate clothing/apparel at UPF sites including a NOTE regarding the use of arm sleeves Revised Section 3.1.3, Head Protection, to clarify use and upkeep of head protection Revised Section 3.1.4, Eye and Face Protection, to include use and maintenance requirements Revised Section 3.1.6, Hand Protection (Gloves), to require the use of hand protection in all active Construction and Warehousing areas and to include new minimum requirements for the selection of hand protection Added new Sections 3.1.3.1, Alternate Forms of Head Protection; 3.1.4.1, Goggles and Sealed Eyewear; 3.1.4.2, Face Shields; and 3.1.4.3, Welding Helmets (Hoods) Added Appendix B, Guide for Shade Numbers in Welding Updated acronyms and definitions Editorial changes This revision is a total rewrite; because of the extent of changes, revision bars are not shown
Re	evision 12
•	This revision incorporates the changes identified in and supersedes PRCN-UPF-CP-205-R11-01, Rev. 0, and PRCN-UPF-CP-205-R11-02, Rev 0.
•	No forms have been edited as part of this revision.
•	A periodic review has been completed for this revision and addresses issues identified in DPR-UPF-CP-205-11.
•	An evaluation determination has been performed confirming that this Command Media implements no quality requirements as tracked in the Programmatic Requirements Management System (PRMS).
•	Description of other changes incorporated; examples are listed below:
	 Revised Section 3.1.1, Safe Work Apparel—Construction/Warehousing Areas, to clarify minimum clothing requirements. Revised Section 3.1.12, High-Visibility Apparel, to remove Equipment Spotter. Deleted Section 3.1.4, Safe Work Apparel—Office Facilities.

Added reference to E-POL-0050, Standards of Conduct and Appearance, for office work.

Moved bullets in Section 3.1.6 to 3.1.6.1, Selection of Hand Protection, and updated note.

Changed phrasing in Section 3.1.3, Head Protection.

Changed phrasing in Section 3.1.4, Eye and Face Protection.

- Changed phrase Construction Support Areas to Construction/Warehousing Support Facilities throughout and added to Definitions.
- Updated Acronyms and template.

Previous revisions on record

CONTENTS

1.0	INIK	CODUCT	ION	5
	1.1	Purpos	se	5
	1.2	Scope		5
2.0	RES	PONSIB	ILITIES	5
	2.1	Site Ma	anager	5
	2.2	Enviror	nmental, Safety and Health Manager, BNI	5
	2.3	Enviror	nmental, Safety and Health Representative, BNI	5
	2.4	Respor	nsible Superintendent	5
	2.5	Superv	visor	6
	2.6	PPE U	ser/Worker	6
3.0	REQ	UIREME	ENTS	6
	3.1	Criteria	a for PPE and Safe Work Apparel	7
		3.1.1	Safe Work Apparel—Construction/Warehousing Areas	7
		3.1.2	Footwear—Construction/Warehousing Areas	7
		3.1.3	Head Protection	8
		3.1.4	Eye and Face Protection	9
		3.1.5	Hearing Protection	10
		3.1.6	Hand Protection (Gloves)	10
		3.1.7	Respiratory Protection Equipment	11
		3.1.8	Fall Protection Equipment	11
		3.1.9	Electrical Protection Equipment	11
		3.1.10	High-Visibility Apparel	11
		3.1.11	Body Protection	12
4.0	REC	ORDS		13
5.0	REF	ERENCE	≣S	13
	5.1	Source	References	13
	5.2	Interfac	cing References	13
6.0	SUP	PLEMEN	NTAL INFORMATION	14
APP	ENDI	X A Acro	onyms and Definitions	15
APP	ENDI	X B Guid	de for Shade Numbers in Welding	16

1.0 INTRODUCTION

1.1 Purpose

This Procedure describes how personal protective equipment (PPE) is selected, inspected, and maintained at the Uranium Processing Facility (UPF).

1.2 Scope

This Procedure is applicable to UPF construction site personnel, subcontractors, vendors, and visitors throughout the duration of the Project.

This Procedure does not address attire worn in project office facilities (e.g., 1060 and 1099 Commerce Park). Reference E-POL-0050, *Standards of Conduct and Appearance*, for further guidance.

2.0 RESPONSIBILITIES

2.1 Site Manager

The Site Manager has the overall responsibility for implementing this Procedure. The Site Manager is also responsible for:

- Ensuring that all project personnel actively participate in the PPE program
- Providing worker support, facilities, and other resources necessary to effectively carry out the PPE program

2.2 Environmental, Safety and Health Manager, BNI

The Environmental, Safety and Health (ES&H) Manager, BNI has the overall authority to interpret the regulations associated with this Procedure and provide guidance as to its intent and application.

2.3 Environmental, Safety and Health Representative, BNI

The ES&H Representative, BNI is responsible for:

- Overseeing compliance of this Procedure via review of field work activities
- Supplying technical advice and interpreting the ES&H codes in this Procedure

2.4 Responsible Superintendent

The Responsible Superintendent is responsible for:

- Being thoroughly familiar with this Procedure and having a full understanding of individual roles and responsibilities regarding compliance with and implementation of this Procedure
- Pre-planning work activities to identify the appropriate PPE to use
- Ensuring that workers understand the requirements of this Procedure

2.5 Supervisor

The Supervisor is responsible for ensuring that the applicable safety controls and processes are incorporated into the planning and execution of the work, and that the workers are using the correct PPE for the assigned task.

2.6 PPE User/Worker

The PPE user/worker is responsible for:

- Using (wearing) PPE as required or specified by this Procedure, jobsite rules, and/or the job hazard analyses (JHAs)/permits
- Reporting situations where assigned PPE does not provide appropriate protection against the hazards that are present
- Inspecting PPE for defects, damage, and/or wear and tear that would make the PPE unsafe to use
- Wearing work apparel as required by this Procedure, company-specific dress standard requirements, and/or the JHAs/permits
- Maintaining work apparel or PPE in accordance with the requirements of this Procedure and the manufacturer's recommendations

3.0 REQUIREMENTS

The proper selection and use of PPE and safe apparel are important elements in the prevention of work-related injuries; however, PPE can only provide a level of protection against injuries and illnesses when it is maintained and used correctly.

This Procedure does not address every type of PPE that could be used at the UPF construction site. For each potentially hazardous task performed at the construction site, appropriate controls, including PPE, are identified and documented in the JHA. Only through appropriate planning can site hazards be determined and proper PPE identified and utilized.

The hazards present in any particular work activity or area and the risks they pose shall be evaluated, and adequate PPE shall be selected based on these evaluations. Key factors to be considered in the selection of PPE include the following:

- PPE shall be capable of providing protection against risk(s) without compromising individual safety
- PPE shall properly fit the user/worker
- PPE shall be compatible with the work to be performed
- PPE shall be of safe design and construction and in compliance with a nationally recognized standard for the work to be performed. Nationally recognized PPE standards include those from the following organizations:
 - American National Standards Institute (ANSI)
 - American Society for Testing and Materials (ASTM)
 - National Fire Protection Association (NFPA)

- National Institute for Occupational Safety and Health (NIOSH)
- Underwriters Laboratories, Inc. (UL)
- PPE shall be used and maintained in a sanitary and reliable condition. PPE that
 has been altered beyond the manufacturer's recommendations is prohibited at the
 UPF construction site. Any such PPE shall be removed from the site and then
 either repaired or destroyed
- Specialized PPE, such as respirators or fall protection, requires additional training and/or medical qualifications before use. These items are outlined in their respective procedures

3.1 Criteria for PPE and Safe Work Apparel

The following subsections identify the various types of PPE utilized on the UPF Project.

- 3.1.1 Safe Work Apparel—Construction/Warehousing Areas
 - Minimum safe work apparel requirements include:
 - Durable shirts with full-length sleeves (continuous) that cover the entire upper torso and arms. Shirts constructed of mesh and/or netting material are prohibited

NOTE: Arm sleeves (synthetic/compression material) combined with short-sleeved shirts do not meet this requirement.

- Full length durable pants in good condition that extend to the ankles
- o Clothing made of natural fibers (e.g., cotton) is recommended
- Avoid wearing loose clothing, rings, and/or necklaces that may contact or get caught or tangled in moving parts, equipment, or energized systems

3.1.2 Footwear—Construction/Warehousing Areas

- Personnel assigned to or visiting Construction/Warehousing areas shall wear safety-toed, sturdy leather work boots that cover the ankle and meet or exceed the requirements of ASTM F2413, Standard Specification for Performance Requirements for Protective (Safety) Toe Cap Footwear. Footwear such as tennis/athletic shoes, open-toed shoes, sandals, moccasins, high heels, boat shoes, and mules are not acceptable footwear at construction and warehousing locations.
- Footwear must be in good condition, free from holes, tears, and other damage that impacts their protective qualities
- Use metatarsal guards in conjunction with the protective footwear as identified in the JHA for the task

3.1.2.1 Footwear—Construction/Warehousing Support Facilities

 Personnel assigned to or visiting Construction/Warehousing Support Facilities (e.g., office trailers or buildings) shall wear sturdy, closed-toed shoes in good condition with a maximum one-inch heel. Footwear such as open-toed shoes,

sandals, moccasins, high heels, boat shoes, flats, mules, etc. are not acceptable footwear

3.1.3 Head Protection

- Hardhats must comply with ANSI Z89.1, American National Standard for Industrial Head Protection. Hardhats must be worn in accordance with the manufacturer's requirements and with the brim facing forward, unless the ES&H Manager or designee provides a written exception. Hardhats, other than those issued by the UPF, or current employer (subcontractor), are prohibited
- Do not wear a ball cap or any unapproved headgear under the hardhat. Hardhats
 fit best when worn directly on the head; however, some garments (e.g., bandanas,
 welding skullcaps, fabric winter liners, and tight-knit stocking caps) may be worn
 under the hardhat as long as these items do not diminish the protective properties
 of the hardhat
- Hardhats must be worn at all times while on the UPF construction site, with the following exceptions:
 - Inside an enclosed vehicle/equipment cab
 - In an office
 - Taking a break in a designated PPE-free area
 - Walking on a designated PPE-free pathway between the office/trailer building and the parking lot
- A hardhat must be worn in conjunction with a welding hood when performing welding or similar hot work operations
- The use of a welding hood alone without a hardhat is allowed if approved/authorized by the Responsible Superintendent and an ES&H Representative. This exemption may occur when welding needs to take place in a location that is physically restrictive and impedes the safe use of a hardhat. The use of alternative head/face protection must be evaluated and implemented as determined by the evaluation
- Store hardhats in a clean and dry location. Never use paint, solvents, hydrocarbon-type cleaners, glue, or other similar chemicals on hardhats. These substances can cause serious damage that may not be visible upon inspection
- Visually inspect the shell and suspension system of the hardhat daily for breakage, cracks, scratches, gouges, hairline cracks, discoloration, chalky appearance, or other unusual condition. Inspect the shell for brittleness by flexing the brim. Any of these conditions indicates a loss of protection from impact and electrical conductivity

3.1.3.1 Alternate Forms of Head Protection

- Alternate forms of head protection, such as bump caps or climbing helmets, may be suitable for select work tasks that require maneuvering in tight spaces with low overhead clearance or overhead hazards from falling/flying objects are not present.
- Use of an alternate form of head protection may be allowed when:

- Hardhats have been demonstrated to be impractical or create an additional hazard
- There is no exposure to falling/flying objects that a hard hat would protect the user from
- The task is evaluated by the Responsible Superintendent and an ES&H Representative and documented on the Field Level Hazard Assessment (FLHA) card for the task

3.1.4 Eye and Face Protection

Eye protection (safety glasses) must meet the specifications of ANSI Z87.1, *American National Standard for Occupational and Educational Personal Eye and Face Protection Devices*.

- Do not wear non-photochromic glasses with tinted lenses inside a building or other structure with limited (temporary) illumination, regardless of whether they are prescription or non-prescription glasses
- Refer to ML-SH-801768-A002, UPF Eye and Face Protection List, for task-specific eye and face protection directives
- Wear eye protection at all times while on the UPF construction site or warehouse area, except when:
 - In an office or a trailer
 - Operating a vehicle or equipment inside an enclosed cab
 - Wearing goggles or respiratory protection that provides equal or greater levels of protection
- Personal prescription eyewear must have impact-rated (ANSI Z87.1) lens, frames, and permanently affixed side shields. If assistance is needed in determining whether specific glasses meet the ANSI standard, then contact a supervisor or an ES&H Representative
- Inspect eye and face protection for damage and wear and tear before each use.
 Before wearing safety glasses, inspect the frames for cracks and deformation and
 inspect the lenses for extensive scratches that limit visibility. Inspect goggles for
 pliability to ensure a good fit to the face. Check the headband and vents, if
 applicable, for signs of degradation and deterioration. Inspect face shields and
 suspension systems for breakage, cracks, scratches, and other detrimental
 conditions
- Safety glasses, goggles, and face shields may be cleaned with an eyeglass cleaner. Do not use ammonia, alkaline cleaners, abrasive cleaning compounds, or solvents

3.1.4.1 Goggles and Sealed Eyewear

Goggles and sealed eyewear (e.g., spoggles) may be required to provide protection from impact, dust, mists, and splashes that are generated by work activities.

Refer to ML-SH-801768-A002 and the activity JHA for task-specific eye and face protection directives.

3.1.4.2 Face Shields

Face shields are required when workers are exposed to flying objects, molten metal, liquid chemicals, or potentially hazardous light radiation. Face shields shall be worn in conjunction with primary eye protection (safety glasses or goggles).

Refer to ML-SH-801768-A002 and the activity JHA for task-specific eye and face protection directives.

3.1.4.3 Welding Helmets (Hoods)

- Personnel performing welding activities shall wear a welding helmet (hood) that meets the requirements of ANSI Z87.1 to protect themselves from welding arc, sparks, and spatter
- Filter lenses shall be selected for the specific welding operation in accordance with ANSI Z49.1, American National Standard for Safety in Welding, Cutting, and Allied Processes, Table 1 – "Guide for Shade Numbers." See Appendix B, Guide for Shade Numbers in Welding

NOTE: Minimum shade requirements for welding operations are identified in the JHA for the activity.

- Safety glasses or goggles must be worn in addition to the welding helmet
- Support personnel in the immediate welding area must wear a similar level of eye and face protection

3.1.5 Hearing Protection

Refer to UPF-CP-312, *Hearing Conservation Program*, for the selection and use of hearing protection equipment.

Care includes discarding disposable earplugs when they possess visible signs of uncleanliness. Reusable earplugs and earmuffs must be cleaned and sanitized. Cleaned and sanitized reusable hearing protection must be kept in a clean, dry area.

Inspect reusable earplugs and earmuffs for wear and tear. Return damaged earmuffs for repair or disposal.

3.1.6 Hand Protection (Gloves)

- Hand protection shall be worn in all active Construction and Warehousing areas with the exception of designated PPE-free areas or for tasks that have been evaluated and require gloves to be removed (e.g., touchscreen use)
- Utilize hand protection appropriate for the hazards and the tasks to be performed. The following are for hand protection:
 - Impacts, cuts, abrasions, and infections
 - Extreme temperatures
 - Chemicals and other hazardous substances
 - Inspect hand protection before each use. Discard damaged and/or worn gloves with holes, tears, and/or other signs of deterioration

3.1.6.1 Selection of Hand Protection

The following are for Hand Protection selection:

- Use only hand protection that is approved and provided by the Project. Refer to ML-SH-801768-A003, *UPF Gloves Matrix*, for a sample of Project approved hand protection.
- Selected hand protection must meet or exceed the following minimum requirements
 - Gloves must meet cut resistance equal to or greater than Level A5 as defined in ANSI/International Safety Equipment Association (ISEA) 105 (2016), American National Standard for Hand Protection Classification, or equivalent
 - Gloves must meet puncture resistance equal to or greater than Level 2 as defined in EN 388 2003, Protective Gloves against Mechanical Risks, or equivalent
 - Where impact hazards are identified (e.g., present risks to hands or fingers such as being caught in/between or struck by/against hazards), gloves with impact protection are required
- **NOTE 1:** Subcontractors shall provide gloves meeting these minimum requirements for standard use on the Project.
- **NOTE 2:** Wearing gloves or loose clothing around rotating equipment can pose a risk of entanglement. An ES&H Representative and Responsible Superintendent will evaluate the task, equipment function, and manufacturer's instructions and provide recommendations for the task.
- 3.1.7 Respiratory Protection Equipment

Refer to UPF-CP-318, *Respirator Use and Issuance*, for the selection, use, and care of respiratory protective equipment.

3.1.8 Fall Protection Equipment

Refer to UPF-MANUAL-SH-A001, *UPF Elevated Work Manual*, for the selection, use, and care of fall protection equipment.

3.1.9 Electrical Protection Equipment

Refer to UPF-MANUAL-CM-001, *Uranium Processing Facility Construction Electrical Safety Manual*, for the selection, use, and care of electrical protective equipment.

3.1.10 High-Visibility Apparel

Project personnel working in active construction areas must wear appropriate, high-visibility vests (or equivalent clothing), per ANSI 107-2004, *American National Standard for High-Visibility Apparel and Headwear* as follows:

- ANSI/ISEA 107 Type "R" Class 2 General construction areas
- ANSI/ISEA 107 Type "R" Class 3 When exposed to traffic from public access highway/street right-of-way or highway/street temporary traffic control zones during nighttime activities

High visibility vests must be rated for flame resistance where hot work processes may negatively impact the vest or the wearer's safety

Additionally, the selection of apparel color shall be in accordance with Table 1 for the specific activity performed.

Table 1. Appropriate Apparel

PERSONNEL	APPAREL COLOR
Safety Watches:	Orange
Personnel Directing Crane Equipment: • Signalman (crane), Bellman	Red
Excavation and Backfill Personnel (Personnel working within an excavation area where heavy equipment is operating)	Yellow/Lime Green
Personnel as directed by the Site Manager and ES&H Manager (e.g., K-31, Laydown 2, Alpha/Bravo/Charlie Area)	Yellow/Lime Green

3.1.11 Body Protection

Specific body protection/clothing may be required for specialized work tasks. The JHA will identify the specific body protection/clothing required.

3.1.11.1 Welding and Associated Hot Work Activities

Clothing shall be selected to minimize the potential for ignition, burning, entrapment of hot sparks, or electric shock. Personnel performing welding and associated hot work activities shall:

- Wear a shirt, jacket, or equivalent that meets the requirements of hazard risk category 2 (in accordance with NFPA 2112, Standard on Flame-Resistant Clothing for Protection of Industrial Personnel Against Short-Duration Thermal Exposures from Fire)
- Wear pants/trousers made from heavier materials (e.g., heavy cotton, denim) that overlap footwear to prevent spatter from entering
- Keep sleeves and collars buttoned
- Wear clothing that is free from pockets, hoods, or cuffs that can trap sparks or slag

NOTE: Pockets that are covered or equipped with closeable flaps are acceptable.

For heavy work (e.g., Carbon Arc Cutting over 500Amps, Oxyfuel Gas Weld over 1/2" plate), flame-resistant leggings or other equivalent means shall be used to give added protection to the legs, when necessary.

Cape sleeves or shoulder covers with bibs made of leather or other flame-resistant material shall be worn during overhead welding, cutting, or other operations, when necessary.

Additional evaluation of hot work PPE will be performed during the hot work permit process and pre-job/FLHA card briefing.

4.0 RECORDS

None

5.0 REFERENCES

5.1 Source References

- 10 Code of Federal Regulations (CFR) 851, Worker Safety and Health Program
- 29 CFR 1926, Occupational Safety and Health Regulations for Construction, Subpart E, Personal Protective and Life Saving Equipment
- Bechtel Corporation, ES&H Core Process 2HI-H030-00205, *Personal Protective Equipment*
- Bechtel Corporation, ES&H Procedure 2HO-E0S0-00001, Hand Protection
- MUTCD, Manual on Uniform Traffic Control Devices for Streets and Highways-2009 Edition
- NFPA 70E, Standard for Electrical Safety in the Workplace
- UPF-CP-200. UPF General Safe Work Practices
- UPF-CP-227, UPF Safety Watches
- Y73-95-802, Confined Space Entry Program

5.2 Interfacing References

- ANSI Z49.1, American National Standard for Safety in Welding, Cutting, and Allied Processes
- ANSI Z87.1, American National Standard for Occupational and Educational Personal Eye and Face Protection Devices
- ANSI Z89.1, American National Standard for Industrial Head Protection
- ANSI/ISEA 107-2004, American National Standard for High-Visibility Apparel and Headwear
- ANSI/ISEA 105 (2016), American National Standard for Hand Protection Classification
- ASTM F2413, Standard Specification for Performance Requirements for Protective (Safety) Toe Cap Footwear
- EN 388 2003, Guide to Safety Glove Standard Gloves Giving Protection to Mechanical Risks

E-POL-0050, Standards of Conduct and Appearance

ML-SH-801768-A002, UPF Eye and Face Protection List

ML-SH-801768-A003, UPF Gloves Matrix

NFPA 2112, Standard on Flame-Resistant Clothing for Protection of Industrial Personnel Against Short-Duration Thermal Exposures from Fire

UPF-CP-312, Hearing Conservation Program

UPF-CP-318, Respirator Use and Issuance

UPF-MANUAL-CM-001, Uranium Processing Facility Construction Electrical Safety Manual

UPF-MANUAL-SH-A001, UPF Elevated Work Manual

6.0 SUPPLEMENTAL INFORMATION

Appendix A, Acronyms and Definitions

Appendix B, Guide for Shade Numbers in Welding

APPENDIX A Acronyms and Definitions

Acronyms

ANSI American National Standards Institute
ASTM American Society for Testing and Materials

CFR Code of Federal Regulations
ES&H Environmental, Safety and Health
FHLA Field Level Hazard Assessment

ISEA International Safety Equipment Association

JHA Job Hazard Analysis

NFPA National Fire Protection Association

NIOSH National Institute for Occupational Safety and Health

PPE Personal Protective Equipment

PRMS Programmatic Requirements Management System

UL Underwriters Laboratories, Inc.UPF Uranium Processing Facility

Definitions

Apparel	Clothing worn to cover the body and extremities, including shirts, pants, jackets, raincoats, etc.
Construction/ Warehousing Support Facilities	Offices and break areas directly supporting construction or warehousing activities, but where physical work is not being performed (e.g., Construction Support Building, On-boarding Center, craft break trailers, warehouse support trailers).
Flagger	A person who actively controls the flow of vehicular traffic in to and/or through public access highways, street right-of-way or highway/street temporary traffic control zones using hand-signaling devices.
Highway	A general term for denoting a public way for purposes of vehicular travel, including the entire area within the right-of-way.
Job Hazard Analysis	A tool used to document workplace activities and related hazards and controls.
Personal Protective Equipment	Safety devices or garments used to protect workers from injury or exposure resulting from contact with chemical, biological, physical, or workplace hazards.
Photochromic Glasses	Eyeglass lenses that darken automatically when exposed to sunlight and then fade back when returning indoors.
Street	See Highway.
Temporary Traffic Control Zone	An area of a highway where road user conditions are changed, because of a work zone or incident, by the use of temporary traffic control devices, flaggers, uniformed law enforcement officers, or other authorized personnel.

APPENDIX B Guide for Shade Numbers in Welding

ANSI Z49.1:2012

Table 1 **Guide for Shade Numbers**

Suggesteda

 $(from\ AWS\ F2.2:2001(R2010), \textit{Lens\ Shade\ Selector})$ Shade numbers are given as a guide only and may be varied to suit individual needs.

Process	Electrode Size in (mm)	Arc Current (Amperes)	Minimum Protective Shade	Suggested ^a Shade No. (Comfort)
Shielded Metal	Less than 3/32 (2.4)	Less than 60	7	_
Arc Welding (SMAW)	3/32-5/32 (2.4-4.0)	60-160	8	10
	5/32-1/4 (4.0-6.4)	160-250	10	12
	More than 1/4 (6.4)	250-550	11	14
Gas Metal Arc Welding		Less than 60	7	1
(GMAW) and Flux Cored Arc		60-160	10	11
Welding (FCAW)		160-250	10	12
		250-500	10	14
Gas Tungsten Arc Welding		Less than 50	8	10
(GTAW)		50-150	8	12
		150-500	10	14
Air Carbon Arc (Light)		Less than 500	10	12
Cutting (CAC-A) (Heavy)		500-1000	11	14
Plasma Arc Welding (PAW)		Less than 20	6	6 to 8
		20-100	8	10
		100-400	10	12
		400-800	11	14
Plasma Arc Cutting (PAC)		Less than 20	4	4
		20-40	5	5
		40-60	6	6
		60–80	8	8
		80-300	8	9
		300-400	9	12
		400–800	10	14
Torch Brazing (TB)		_	-	3 or 4
Torch Soldering (TS)		_	-	2
Carbon Arc Welding (CAW)		_	-	14
	Plate Thio	ckness		Suggested ^a Shade No.
	in	mm		(Comfort)
Oxyfuel Gas Welding (OFW)	II J 1/0	TT-do-2		4 5

Light Medium Under 1/8 Under 3 4 or 5 1/8 to 1/2 3 to 13 5 or 6 Heavy Over 1/2 Over 13 6 or 8 Oxygen Cutting (OC) Light Medium Under 1 Under 25 3 or 4 1 to 6 25 to 150 4 or 5 Heavy Over 6 Over 150

a As a rule of thumb, start with a shade that is too dark to see the weld zone. Then go to a lighter shade which gives sufficient view of the weld zone without going below the minimum. In oxyfuel gas welding, cutting, or brazing where the torch and/or the flux produces a high yellow light, it is desirable to use a filter lens that absorbs the yellow or sodium line of the visible light spectrum.

DISCLAIMER

This work of authorship and those incorporated herein were prepared by Consolidated Nuclear Security, LLC (CNS) as accounts of work sponsored by an agency of the United States Government under Contract DE-NA-0001942. Neither the United States Government nor any agency thereof, nor CNS, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility to any non-governmental recipient hereof for the accuracy, completeness, use made, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise, does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency or contractor thereof, or by CNS. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency or contractor (other than the authors) thereof.

COPYRIGHT NOTICE

This document has been authored by Consolidated Nuclear Security, LLC, under Contract DE-NA-0001942 with the U.S. Department of Energy/National Nuclear Security Administration, or a subcontractor thereof. The United States Government retains and the publisher, by accepting the document for publication, acknowledges that the United States Government retains a nonexclusive, paid-up, irrevocable, world-wide license to publish or reproduce the published form of this document, prepare derivative works, distribute copies to the public, and perform publicly and display publicly, or allow others to do so, for United States Government purposes.